






## Quick Start for the HOBO® MX2300 Series Data Loggers

- 1 • Download HOBObconnect® to a phone or tablet from the App Store® or Google Play™.  
• Download HOBObconnect to a Windows® computer from [www.onsetcomp.com/products/software/hobobconnect](http://www.onsetcomp.com/products/software/hobobconnect).
- 2 Press the button on the logger to wake it up. Open the app. Enable Bluetooth® in your device settings if prompted.
- 3 Tap Devices in the app. Tap the logger in the app to connect to it. (Press the button on the logger again to bring it to the top of the list if you are working with multiple loggers.) If the logger does not appear, make sure it is within range of your phone, tablet, or computer.
- 4 Tap  to set up the logger. Choose your logger settings and then tap  to save the settings to the logger.
- 5 The logger will begin logging data based on the settings you selected in the app. Press the button on the logger if you set it up to start logging with a button push. Deploy the logger to the location where you will be monitoring the conditions.
- 6 To offload data from the logger to your device, tap Devices and press the button on the logger to wake it up (if necessary). Connect to the logger and tap . To view or export the data, tap HOBO Files, tap  (if applicable), and tap .



For detailed specifications and information about the logger, scan the code at left or go to [www.onsetcomp.com/support/manuals/20923-mx2300-manual](http://www.onsetcomp.com/support/manuals/20923-mx2300-manual).



**WARNING:** Do not cut open, incinerate, heat above 85°C (185°F), or recharge the lithium battery. The battery may explode if the logger is exposed to extreme heat or conditions that could damage or destroy the battery case. Do not dispose of the logger or battery in fire. Do not expose the contents of the battery to water. Dispose of the battery according to local regulations for lithium batteries.



1-508-759-9500 (U.S. and International)  
1-800-LOGGERS (564-4377) (U.S. only)  
[www.onsetcomp.com/support/contact](http://www.onsetcomp.com/support/contact)

© 2016–2021 Onset Computer Corporation. All rights reserved. Onset, HOBO, and HOBObconnect are registered trademarks of Onset Computer Corporation. App Store is a service mark of Apple Inc. Google Play is a trademark of Google LLC. Windows is a registered trademark of Microsoft Corporation. Bluetooth is a registered trademark of Bluetooth SIG, Inc. All other trademarks are the property of their respective companies.

This product has been manufactured by Onset Computer Corporation and in compliance with Onset's ISO 9001:2015 Quality Management System.

Patent #: 8,860,569

20922-I MAN-QSG-MX2300