



## RXW-SMC-xxx Sensor

### HOBOnet Soil Moisture EC-5 Sensor

The HOBOnet Wireless Soil Moisture Sensor integrates the field-proven ECH2O™ EC5 Sensor and provides readings directly in volumetric water content. The sensor's high-frequency design minimizes sensitivity to salinity and textural effects, and gives it a wide measurement range. HOBOnet Wireless Sensors communicate data directly to the RX3000 weather station or pass data through other wireless sensors back to the central station. They are preconfigured and ready to deploy, and data is accessed through HOBOLink, Onset's innovative cloud-based software platform.



#### Supported Measurements:

Soil Moisture

#### Key Advantages:

#### Sensor Features

- $\pm 3\%$  accuracy in typical soil conditions, and  $\pm 2\%$  accuracy with soil-specific calibration
- Measures a 0.3-liter volume of soil for taking readings at a specific depth or in a container
- High-frequency (70 MHz) circuit provides good accuracy even in high-salinity and sandy soils

#### Wireless Features

- 900 MHz wireless mesh self-healing technology
- 450 to 600 meter (1,500 to 2,000 feet) wireless range and up to five hops
- Up to 50 wireless sensors per RX3000
- Simple button-push to join the HOBOnet wireless network
- Onboard memory to ensure no data loss
- Powered by rechargeable AA batteries and built-in solar panel




## RXW-SMC-xxx Sensor Specifications

### Sensor

<b>Measurement Range</b>	In soil: 0 to 0.550 m /m (volumetric water content)
<b>Extended Range</b>	-0.401 to 2.574 m /m
<b>Accuracy</b>	$\pm 0.031$ m /m ( $\pm 3.1\%$ ) typical 0 to 50°C (32° to 122°F) for mineral soils up to 8 dS/m and $\pm 0.020$ m /m ( $\pm 2\%$ ) with soil specific calibration; see Notes 2 and 3
<b>Resolution</b>	0.0007 m /m (0.07%)
<b>Volume of Influence</b>	0.3 liters (10.14 oz)
<b>Sensor Frequency</b>	70 MHz

**Sensor Operating Temperature Range** 0° to 50°C (32° to 122°F). Although the sensor probe and cable can safely operate at below-freezing temperatures (to -40°C/F), the soil moisture data collected at these extreme temperatures is outside of the sensor's accurate measurement range.

### Wireless Mote

<b>Operating Temperature Range</b>	-25° to 60°C (-13° to 140°F) with rechargeable batteries -40 to 70°C (-40 to 158°F) with lithium batteries
<b>Radio Power</b>	12.6 mW (+11 dBm) non-adjustable
<b>Transmission Range</b>	Reliable connection to 457.2 m (1,500 ft) line of sight at 1.8 m (6 ft) high Reliable connection to 609.6 m (2,000 ft) line of sight at 3 m (10 ft) high
<b>Wireless Data Standard</b>	IEEE 802.15.4
<b>Radio Operating Frequencies</b>	RXW-SMC-900: 904–924 MHz RXW-SMC-868: 866.5 MHz RXW-SMC-922: 916–924 MHz
<b>Modulation Employed</b>	OQPSK (Offset Quadrature Phase Shift Keying)
<b>Data Rate</b>	Up to 250 kbps, non-adjustable
<b>Duty Cycle</b>	<1%
<b>Maximum Number of Motes</b>	50 motes per one RX Wireless Sensor Network
<b>Battery Type/ Power Source</b>	Two AA 1.2 V rechargeable NiMH batteries powered by built-in solar panel or two AA 1.5 V lithium batteries for operating conditions of -40 to 70°C (-40 to 158°F)
<b>Battery Life</b>	With NiMH batteries: Typical 3–5 years when operated in the temperature range -20° to 40°C (-4°F to 104°F) and positioned toward the sun (see Deployment and Mounting), operation outside this range will reduce the battery service life With lithium batteries: 1 year, typical use
<b>Memory</b>	16 MB
<b>Dimensions</b>	Cable length: 5 m (16.4 ft) Mote: 16.2 x 8.59 x 4.14 cm (6.38 x 3.38 x 1.63 inches)
<b>Weight</b>	Mote: 223 g (7.87 oz)
<b>Materials</b>	Sensor: Weatherproof Mote: PCPBT, silicone rubber seal
<b>Environmental Rating</b>	Mote: IP67, NEMA 6
<b>Compliance Marks</b>	 RXW-SMC-900  RXW-SMC-868  RXW-SMC-922

## Contact Us

Sales (8am to 5pm ET, Monday through Friday)

- ▶ Email [sales@onsetcomp.com](mailto:sales@onsetcomp.com)
- ▶ Call 1-508-759-9500
- ▶ In U.S. toll free 1-800-564-4377
- ▶ Fax 1-508-759-9100

Technical Support (8am to 8pm ET, Monday through Friday)

- ▶ Contact Product Support [www.onsetcomp.com/support/contact](http://www.onsetcomp.com/support/contact)
- ▶ Call 1-508-759-9500
- ▶ In U.S. toll free 1-877-564-4377

Onset Computer Corporation  
470 MacArthur Boulevard  
Bourne, MA 02532

# HOBO<sup>®</sup>

Data Logging Solutions  
Australia & New Zealand

### Australia

1300 186 107  
[sales@hobodataloggers.com.au](mailto:sales@hobodataloggers.com.au)  
[www.hobodataloggers.com.au](http://www.hobodataloggers.com.au)

### New Zealand

0800 104 904  
[sales@onetemp.co.nz](mailto:sales@onetemp.co.nz)  
[www.onetemp.co.nz](http://www.onetemp.co.nz)