

Quick Start for the HOBO® MX CO₂ Logger (MX1102A)

IMPORTANT: The CO₂ sensor within this logger can experience measurement drift during storage and shipment. Start the logger as described below and perform a manual calibration as described in Step 4. Note that improper manual calibration can cause incorrect sensor readings.

- 1** Install the batteries in the logger. Use a Phillips-head screwdriver to open the battery cover on the back of the logger and insert four AA batteries observing polarity. Screw the cover back in place.

- 2**
 - Download HOBObconnect® to a phone or tablet from the App Store® or Google Play™ or download HOBObconnect to a Windows® computer from www.onsetcomp.com/products/software/hobobconnect.
 - Download HOBOWare® to a computer from www.onsetcomp.com/products/software/hoboware.

- 3** To configure the logger with HOBObconnect:
 - a. Open the app. Enable Bluetooth® in your device settings if prompted.
 - b. Tap Devices in the app. Tap the logger tile in the app to connect to the logger. If the logger does not appear, make sure it is within range of your phone, tablet, or computer.
 - c. Tap Configure & Start to set up the logger.
 - d. Choose your logger settings. Tap the CO₂ Sensor Altitude Settings and select both manual and auto calibration. For best accuracy, we recommend manually calibrating the logger immediately after logging begins. Enter the altitude if the logger will be deployed above or below 305 meters (1,000 feet).
 - e. Tap Start to save the settings to the logger.

The logger begins logging data based on the settings you select in the app. Press the start button on the logger if you set it up to start logging with a button push.

To configure the logger with HOBOWare:

- a. Connect the logger to the computer with a USB cable. From the Device menu in HOBOWare, select Launch.
- b. Choose your logger settings. Click the CO₂ Settings button and select manual and auto calibration (both are selected by default). Manual calibration immediately after logging begins is recommended for best accuracy. Enter the altitude if the logger will be deployed above or below 305 meters (1,000 feet). Click Save.
- c. Click the Start button when finished. Note that the Start button text changes based on your Start Logging selection.

22467-J MAN-MX1102A-QSG

Quick Start for the HOBO® MX CO₂ Logger (MX1102A)

IMPORTANT: The CO₂ sensor within this logger can experience measurement drift during storage and shipment. Start the logger as described below and perform a manual calibration as described in Step 4. Note that improper manual calibration can cause incorrect sensor readings.

- 1** Install the batteries in the logger. Use a Phillips-head screwdriver to open the battery cover on the back of the logger and insert four AA batteries observing polarity. Screw the cover back in place.

- 2**
 - Download HOBObconnect® to a phone or tablet from the App Store® or Google Play™ or download HOBObconnect to a Windows® computer from www.onsetcomp.com/products/software/hobobconnect.
 - Download HOBOWare® to a computer from www.onsetcomp.com/products/software/hoboware.

- 3** To configure the logger with HOBObconnect:
 - a. Open the app. Enable Bluetooth® in your device settings if prompted.
 - b. Tap Devices in the app. Tap the logger in the app to connect to it. If the logger does not appear, make sure it is within range of your phone, tablet, or computer.
 - c. Tap Configure & Start to set up the logger.
 - d. Choose your logger settings. Tap the CO₂ Sensor Altitude Settings and select both manual and auto calibration. For best accuracy, we recommend manually calibrating the logger immediately after logging begins. Enter the altitude if the logger will be deployed above or below 305 meters (1,000 feet).
 - e. Tap Start to save the settings to the logger.

The logger will begin logging data based on the settings you selected in the app. Press the start button on the logger if you set it up to start logging with a button push.

To configure the logger with HOBOWare:

- a. Connect the logger to the computer with a USB cable. From the Device menu in HOBOWare, select Launch.
- b. Choose your logger settings. Click the CO₂ Settings button and select manual and auto calibration (both are selected by default). Manual calibration immediately after logging begins is recommended for best accuracy. Enter the altitude if the logger will be deployed above or below 305 meters (1,000 feet). Click Save.
- c. Click the Start button when finished. Note that the Start button text changes based on your Start Logging selection.

22467-J MAN-MX1102A-QSG

-
- 4** We recommend that you perform manual calibration immediately after logging begins to ensure the best CO₂ accuracy. **Important:** If you do not follow these instructions as described, the sensor readings will be incorrect and you will need to manually calibrate the logger again.
- Take the logger outside in fresh air. Weather conditions should be dry or the calibration value may be incorrect.
 - Press and hold the Calibrate button on the logger for 5 seconds until it beeps. The logger will then calibrate for 5 minutes; leave it outside during the process.
 - The CO₂ and Calibrate symbols on the LCD will flash while manual calibration is underway. Return the logger inside once the calibration is complete.

Note: If the logger was configured with both manual and auto calibration selected, auto calibration will occur every eight days after a manual calibration has occurred. Auto calibration requires that the building where the logger is deployed to be empty at least once during the eight-day period. Alternatively, you can perform a manual calibration as described above at any time. See the product manual for more details on calibration.

- 5** Deploy the logger using the included mounting materials.
-

Tap Devices, connect to the logger, and then tap Download Data.

- 6** After the download is complete, you can choose to export and share the file. You can also view your files by tapping Data at the bottom of the screen.

To offload data from the logger with HOBOWare, select Readout from the Device menu. Save the data when prompted and plot as desired.



For detailed specifications and information about this logger, refer to the HOBOWare® MX CO₂ Logger (MX1102A) Manual at www.onsetcomp.com/resources/documentation/22504-mx1102a-manual or scan the code at left.



© 2015–2023 Onset Computer Corporation. All rights reserved. Onset, HOBOWare, HOBOWare, and HOBOWareconnect are registered trademarks of Onset Computer Corporation. App Store is a service mark of Apple Inc. Google Play is a trademark of Google LLC. Windows is a registered trademark of Microsoft Corporation. Bluetooth is a registered trademark of Bluetooth SIG, Inc. All other trademarks are the property of their respective companies.

This product has been manufactured by Onset Computer Corporation and in compliance with Onset's ISO 9001:2015 Quality Management System.

Patent #: 8,860,569

22467-J MAN-MX1102A-QSG

- 4** We recommend that you perform manual calibration immediately after logging begins to ensure the best CO₂ accuracy. **Important:** If you do not follow these instructions as described, the sensor readings will be incorrect and you will need to manually calibrate the logger again.
- Take the logger outside in fresh air. Weather conditions should be dry or the calibration value may be incorrect.
 - Press and hold the Calibrate button on the logger for 5 seconds until it beeps. The logger will then calibrate for 5 minutes; leave it outside during the process.
 - The CO₂ and Calibrate symbols on the LCD will flash while manual calibration is underway. Return the logger inside once the calibration is complete.

Note: If the logger was configured with both manual and auto calibration selected, auto calibration will occur every eight days after a manual calibration has occurred. Auto calibration requires that the building where the logger is deployed to be empty at least once during the eight-day period. Alternatively, you can perform a manual calibration as described above at any time. See the product manual for more details on calibration.

- 5** Deploy the logger using the included mounting materials.
-

Tap Devices, connect to the logger, and then tap Download Data.

- 6** After the download is complete, you can choose to export and share the file. You can also view your files by tapping Data at the bottom of the screen.

To offload data from the logger with HOBOWare, select Readout from the Device menu. Save the data when prompted and plot as desired.



For detailed specifications and information about this logger, refer to the HOBOWare® MX CO₂ Logger (MX1102A) Manual at www.onsetcomp.com/resources/documentation/22504-mx1102a-manual or scan the code at left.



© 2015–2023 Onset Computer Corporation. All rights reserved. Onset, HOBOWare, HOBOWare, and HOBOWareconnect are registered trademarks of Onset Computer Corporation. App Store is a service mark of Apple Inc. Google Play is a trademark of Google LLC. Windows is a registered trademark of Microsoft Corporation. Bluetooth is a registered trademark of Bluetooth SIG, Inc. All other trademarks are the property of their respective companies.

This product has been manufactured by Onset Computer Corporation and in compliance with Onset's ISO 9001:2015 Quality Management System.

Patent #: 8,860,569

22467-J MAN-MX1102A-QSG